



VIMAR
EQUIPMENT

CROSSWIND WINTERIZATION PROCEDURE

In freezing weather, if the equipment is to be left exposed to sub-freezing temperatures, the following procedure should be followed:

1. Remove drain plug at rear bumper
2. Remove water filter and housing and store in cab
3. Turn on water system to purge water out of lines
 - * **This should only take 15-20 seconds**
4. Open drain cock at water manifold (located left side of sweeper)
 - * **The manifold is in front of the suction tube on units built after 2010**
5. Open drain cock at high pressure pump if equipped
6. If equipped, use air purge system to remove any remaining water
 - * **Located by the water filter housing is an air valve, use shop air to purge out water.**

WARNING: FAILURE TO PROPERLY WINTERIZE CAN LEAD TO COSTLY DAMAGE TO WATER COMPONENTS.

If you have any concerns do not hesitate to call 604-430-4274